

INSTALLATION AND OPERATION MANUAL FOR ELECTRIC RESTAURANT RANGES MODELS E24L, E36L, E48L, & E60L SERIES




MODEL E36L


TABLE OF CONTENTS

ELECTRIC RESTAURANT RANGE MODELS	4
GENERAL	5
INSTALLATION	6
Unpacking	6
Location	6
Installation Codes and Standards	6
Assembly	6
Electrical Connections	8
Leveling	8
OPERATION	9
Controls	9
Before First Use	10
Surface Plates	10
Griddle	11
Broiler (Accessory)	12
Oven	12
Power Outage	13
Cleaning	13
MAINTENANCE	15
Service and Parts Information	15


ELECTRIC RESTAURANT RANGE MODELS




E24L




E24SL




E24FL




E36L




E36SL




E36FL




E36XL




E48L




E48SL




E48FL




E48XL




E60L




E60SL




E60FL




E60XL




E24L



E36L



E48L



E60L

PL-51578

Installation, Operation and Care of MODEL E24L, E36L, E48L & E60L SERIES ELECTRIC RESTAURANT RANGES

KEEP THESE INSTRUCTIONS FOR FUTURE USE

GENERAL

The manufacturer suggests that you thoroughly read this entire manual and carefully follow all of the instructions provided.

Your Vulcan-Hart range is produced with quality workmanship and material. Proper installation, usage and maintenance of your range will result in many years of satisfactory performance.

Electric Restaurant Ranges are equipped as follows:

MODEL	DESCRIPTION
E24L E24SL E24FL	(4) French Plates / Standard Oven 12" Griddle / (2) French Plates / Standard Oven 24" Griddle / Standard Oven
E36L E36SL E36FL E36XL	(6) French Plates / Standard Oven 12" Griddle / (4) French Plates / Standard Oven 24" Griddle / (2) French Plates / Standard Oven 36" Griddle / Standard Oven
E48L E48SL E48FL E48XL	(8) French Plates / (2) Standard Ovens 12" Griddle / (6) French Plates / (2) Standard Ovens 24" Griddle / (4) French Plates / (2) Standard Ovens 36" Griddle / (2) French Plates / (2) Standard Ovens
E60L E60SL E60FL E60XL	(10) French Plates / (2) Standard Ovens 12" Griddle / (8) French Plates / (2) Standard Ovens 24" Griddle / (6) French Plates / (2) Standard Ovens 36" Griddle / (4) French Plates / (2) Standard Ovens

Standard surface plates are solid French-type cast iron 9¹/₂" in diameter with 2000 W. heating elements.

One hot top section or two optional high-speed round tubular plates (2000 W. each) may be substituted for two French plates. High-speed round tubular plates are not recommended for stock pot work.

INSTALLATION

UNPACKING

Immediately after unpacking, check for possible shipping damage. If the range is found to be damaged, save the packaging material and contact the carrier within 15 days of delivery.

Remove all shipping wire, wood blocking, and accessories. Uncrate the high shelf, backguards and/or broiler.

Before installing, verify that the electrical service agrees with the specifications on the rating plate located behind the kick panel on the left side. If the supply and equipment requirements do not agree, contact your dealer or Vulcan-Hart immediately.

LOCATION

The installation location must allow adequate clearances for servicing and proper operation. A minimum front clearance of 40" is required.

INSTALLATION CODES AND STANDARDS

Your Vulcan range must be installed in accordance with state and local codes, or in the absence of local codes, with National Electrical Code ANSI/NFPA-70 (latest edition) available from The National Fire Protection Association, Batterymarch Park, Quincy, MA 02269.

ASSEMBLY

Model ESB Broiler/Backguard

In E36L and E60L Series, slide the legs of the broiler inside the channels provided in the back of the range (in E60L Series, the broiler is mounted between the center and the right-hand channel), until the two holes on each side line up. Fasten with the bolts and nuts provided.

In a similar way, mount the backguard to the left side of the broiler.

High Shelf

The high shelf for this range is shipped knocked down and is included in the range crate. The splasher back and heat shield are bolted together and shipped attached to the rear of the range. The hardware required to assemble the shelf is packed in the oven.

1. Remove the splasher back and heat shield from the rear of the range.
2. Remove the heat shield from the splasher back by removing two sheet metal screws.

3. Assemble heat shield to splasher back (Fig. 1). Top edge of heat shield must be placed inside the rear top flange of the splasher back.

CAUTION: It is essential that the heat shield in the back of the high shelf be installed in such a way that the bent section at the bottom be inward, touching the rear wall of the range, thereby allowing the stack action of the double wall back splasher to draw air through the area below the top surface units.




Fig. 1

4. With top cooking plates in their normal position, assemble splasher back to range and fasten in place with $\frac{1}{4}$ -20 screws and nuts provided (Fig's. 2 & 3) .




Fig. 2



Fig. 3

5. Place shelf in position on splasher and fasten with $\frac{1}{4}$ -20 screws and nuts provided (Fig's. 4 & 5) .



Fig. 4



Fig. 5

ELECTRICAL CONNECTIONS

WARNING: ELECTRICAL AND GROUNDING CONNECTIONS MUST COMPLY WITH THE APPLICABLE PORTIONS OF THE NATIONAL ELECTRICAL CODE AND/OR OTHER LOCAL ELECTRICAL CODES.

WARNING: DISCONNECT ELECTRICAL POWER SUPPLY AND PLACE A TAG AT THE DISCONNECT SWITCH TO INDICATE THAT YOU ARE WORKING ON THE CIRCUIT.

On ranges equipped with a Model ESB Broiler, bring the leads A1, A2, B1 and B2 (on 240 volt models, the leads are X, Y, N) which are connected to the broiler down and through the burner box to the switch panel compartment. Connect them to the appropriate circuit breaker or terminal block as shown on the wiring diagram. The wiring diagram is located behind the kick panel.

Position the range in its final location. Bring conduit containing the proper supply wire to the range through the knockout located on the left side of the range. Select the size and type of field wire in accordance with the National Electrical Code suitable for carrying the equipment's rated amps and voltage. Use field wires suitable for 75°C on units carrying more than 80 amps.

Connect supply leads to field terminal block and green grounding lead to the labeled ground lug.

Ranges wired for 3-phase service may be changed to 1-phase, or vice versa, by simply relocating two wires on the terminal block, as shown on the wiring diagram and schematic decal attached to the range.


LEVELING

Place a carpenter's level on top of the range and level the range front-to-back and side-to-side by turning the adjustable feet .

OPERATION

WARNING: THE RANGE AND ITS PARTS ARE HOT. BE VERY CAREFUL WHEN OPERATING, CLEANING OR SERVICING THE RANGE.

CONTROLS (Fig. 6)



Model E36L Shown

Fig. 6

- | | |
|---|--|
| Element Controls | — Infinite load switches that control and maintain heat to the surface plates. The controls are arranged in pairs; the left knob controls the front plate and the right knob controls the rear plate. |
| Element Indicator Lights | — When lit, indicate heat is being supplied to the element. |
| Hot Top Switch | — (Not shown.) A 4-heat switch (HI, MED HI, MED LO, LO) controls and maintains heat to the hot top section. |
| Griddle Thermostat | — (Not shown.) Regulates the amount of heat needed to maintain the set temperature. Each 12" section of the griddle has its own thermostat with a temperature range of 150°F to 550°F. |
| Griddle Indicator Light | — (Not shown.) Will be lit until the selected temperature is reached or when it is being maintained. |
| Oven Thermostat | — Regulates the amount of heat needed to control and maintain oven temperature around the desired set temperature. The temperature range is from 150°F to 550°F. Turn dial counterclockwise to increase temperature and clockwise to decrease temperature. |
| Infinite Switch for Oven Top Heating Element | — Provides directional heat control. Adjust as needed for the amount of top heat required. |
| Oven Indicator Light | — Will be lit until the selected temperature is reached or when it is being maintained. |

BEFORE FIRST USE

Cleaning

Clean the range and all accessories with water and a mild detergent. Rinse thoroughly and wipe dry with a soft clean cloth.

Griddle Seasoning (SL, FL and XL Models)

A new griddle surface must be seasoned to do a good cooking job. The metal surface of the griddle is porous. Food tends to get trapped in these pores and stick; therefore, it is important to "season" or "fill up" these pores with cooking oil before cooking. Seasoning gives the surface a slick, hard finish from which the food will release easily.

To season, heat griddle top section at a low setting. Pour one ounce of cooking oil per square foot of surface over the griddle top section. With an insulated cloth, spread the oil over the entire griddle surface to create a thin film. Wipe off any excess oil with an insulated cloth.

Repeat this procedure 2 to 3 times until the griddle has a slick surface.

SURFACE PLATES

French plates are most efficient when used with utensils having a maximum inside diameter of 10" or a minimum inside diameter of 9". Stock pots of 9, 12 and 16 qt. capacities are recommended for bulk cooking. (Fig. 7)




Fig. 7

The solid surface plates are rated for 2000 Watts and are controlled by an infinite heat switch. A solid surface plate will reach cooking temperature from room temperature in 5 to 7 minutes at a HI switch setting.

Each control knob is marked HI, MED, LO, MED-LO, and VERY-LO. The HI setting is full heat. Use the HI setting to start cooking quickly and to bring water to a boil.

Some DO'S and DO NOT'S of Surface Cooking

DO use utensils to fit the tops (9" to 10" inside diameter).

DO use flat-bottomed, straight-sided pots and pans.

DO use covers for stock pot work. Water will boil much sooner and much less heat is required for cooking in a covered container. Less water may be used, thereby retaining vitamins and minerals in the food.

DO turn off plates a few minutes before cooking is completed to use the heat stored in the plate.

DO NOT allow surface plates to idle unloaded at HI switch settings. The surface plates will reach very high temperatures, and this can cause the casting to warp or dome. Plates idled at a setting of MED-LO and turned to HI when loaded, will perform bulk cooking jobs just as rapidly, without damage to the plates.

Optional High-Speed Surface Plates

If so ordered, your range may be equipped with one or more heavy duty high-speed plates. These optional high-speed tubular-type surface plates are available for use with fry pans and stock pots up to 10" in diameter or 16 qt. capacity. While the surface plate cooking information above applies, there are some differences:

High-speed plates are for quick heating and cooking.

Heavy duty high-speed plates will preheat to cooking temperatures in 2 to 5 minutes.

GRIDDLE

See BEFORE FIRST USE in this manual for griddle seasoning procedure.

CAUTION: This griddle plate is steel, but the surface is relatively soft and can be scored or dented by the careless use of a spatula or scraper. Be careful not to dent, scratch, or gouge the plate surface. Do not try to knock off loose food that may be on the spatula by tapping the corner edge of the spatula on the griddle surface.

All models with a suffix of SL have a 12" x 24" griddle which has one 3400 W. heating element. All models with a suffix of FL have a large double griddle (24" x 24") which has two 3400 W. heating elements. Models E36XL, E48XL and E60XL have a 36" griddle with three 3400 W. heating elements. Each heating element is individually controlled by a thermostat with a range of 150°F to 550°F.

The griddle has a $\frac{7}{8}$ " high edge around 3 sides. The right side has a drip edge for drainage into the slide-out grease collector mounted on the right side of the range.

The griddle will preheat to 400°F in approximately 10 minutes, or will come up to 400°F from a 300°F setting in 3 minutes. During breakfast, you may set one control at 300°F for eggs and the other at 375°F for pancakes, bacon, etc. During lunch, you might use the whole area at 350°F for hamburgers, or set one side for hamburgers and the other at 400°F for minute steaks and grilled cheese sandwiches.

Between serving periods, foods that take longer to cook, such as soup or stew, may be simmered in a large container set on the griddle surface. If no grilled items are to be served, pans of food may be kept hot on the griddle at a setting of 150°F to 250°F.

BROILER (Accessory)

The high-shelf broiler is available on Models E36L and E60L except those models supplied with hot top sections. The broiler is equipped with 2 tubular 3000 W. heating elements independently controlled by two infinite heat switches. The switches are located on the switch panel at the right of the broiler. The top switch controls the element for the left half of the broiler, and the bottom switch controls the element for the right half of the broiler.

Each dial is marked HI, MED, LO, MED-LO, and VERY-LO. HI is used for quick searing of steaks. VERY-LO is best suited for warming, melting cheese on pie, etc. The intermediate positions provide flexibility for a variety of products, such as fish, liver, au gratins, etc. By setting the switch for one-half of the broiler at HI and the other from MED to VERY-LO, a variety of broiler foods can be properly handled.

The grid and drip shield can be used in 3 different positions. Most broiling should be done with the rack in the top or center position. The lower position may be used for browning deep casseroles.

The rack has a removable metal drip shield supported at the front of the grid. Grease drains from the drip shield into the bottom of the broiler and is collected in the removable grease collector under the left bottom of the broiler.

A double-deck 24" high shelf is mounted to the left of the broiler on E60L ranges.

OVEN

CAUTION: Never cover the oven deck or rack with aluminum foil. The oven will not operate properly and the range may be damaged.

The fully insulated oven is 26¹/₄" wide x 22¹/₂" deep x 14¹/₂" high, with an effective rack or deck area 25" wide x 22" deep. Bake sheets or roast pans 20" x 22" (restaurant size) are recommended. Place pans at least ¹/₂" from the walls and back and 2" from the door when closed. The oven will accommodate 6" to 7" or 5" to 8" layer cake or pie pans. It is not designed to perform satisfactorily with an 18" x 26" pan, or with 2-200 series (12³/₄" x 20³/₄") food service pans.

Model E24L and E36L ranges have a single oven; Model E48L and E60L ranges have two separate ovens. Each oven is equipped with top and bottom heating elements. The top element has an infinite heat switch for directional heat control.

The oven has an input of 5000 W., 1250 W. for the top element, and 3750 W. for the bottom element.

Preheating

Thoroughly preheat the oven by setting the switch and the thermostat to the desired temperature. When the red light goes out, the oven is ready for use. For full loads and delicate baked products, it may be desirable to allow the oven to cycle (red light on and off) a second time before loading.

Baking

Most products can be baked directly on the deck with the top switch set between 3 and 5. Hard-to-brown products, such as corn bread or biscuits, may require a top switch setting of MED to HI.

If both the oven deck and oven rack are fully loaded, it will be necessary to switch the pans from the rack to the deck and the pans from the deck to the rack when approximately half the cooking time has elapsed. If this is not done, the bottom of products on the rack and the top of the product on the deck will not cook properly.

Roasting

Place meat on a rack in an open pan with sides sufficiently high to retain the drippings. Roasting may be done on the oven rack or the deck. For best results, roast at the low temperatures of 200°F to 325°F recommended by the Department of Agriculture and the American Meat Institute. Most meats may be roasted with the infinite heat switch set at HI. If heavy browning on poultry is not desired, the switch should be set between MED-LO and VERY-LO.

The top oven element is not suitable for broiling.

POWER OUTAGE

If a power outage occurs, the range will automatically shut down. When power is restored, the range will automatically resume normal functions after it has preheated for 5 minutes. If the range is left unattended during the power outage, turn all control knobs/switches OFF. When power is restored, turn desired control knobs/switches back ON. The unit will be preheated in 5 minutes and normal cooking operations can be resumed.

CLEANING

WARNING: DISCONNECT ELECTRICAL POWER SUPPLY BEFORE CLEANING.

Do not use Dawn dish detergent to clean the exterior or interior components of the range.

Do not use scouring powder. It is extremely difficult to remove completely. It can build up accumulations that will damage the range.

Clean all parts of the range and the oven with a soft cloth and warm water and detergent. Rinse thoroughly and wipe dry with a soft clean cloth.

High-Speed Surface Plates

High-speed surface plates may be raised for cleaning. **CAUTION: Replace surface plates in their original position in the plate support. Twisting or rotating of the surface plates can damage wiring.**

Remove the drip tray under the high-speed surface plates. After cleaning replace in the same positions.

Griddle

Scrape the griddle with a spatula after each use. Daily, or more often if necessary, empty and wipe out the grease collector. Weekly, or more often if necessary, thoroughly clean the griddle surface. You may use a griddle screen or stone with a little grease, rubbing with the grain of the metal while it is still warm, or use water and detergent with a steel brush. The detergent must be thoroughly removed. After each thorough cleaning, the griddle must be reseasoned (see BEFORE FIRST USE in this manual).

Avoid build-up of caked grease under the drip edge and around the outside edges of the griddle.

If the griddle is to be shut down for an extended period, put a heavy coat of grease over the griddle plate.

Broiler

Empty grease collector as often as necessary. It is recommended that the grease collector be emptied whenever it is $\frac{3}{4}$ filled. Remove grease collector slowly and be careful of liquid wave action. After each day's use, empty and wash the grease collector and wash the grid and drip shield.

Clean the inside bottom, back and sides of the broiler compartment as often as necessary, with special care to clean the inside surface of the baffle across the front top of the broiler.

Oven

Clean oven and oven door daily, especially if fruit pies or tomato sauces were baked, meats roasted, and if there have been spillovers.

If the oven liners and decks are heavily soiled, ammonia or oven cleaner may be used to remove spillage of burned on sugar and grease.

Clean the oven door gasket. DO NOT USE STRONG OVEN CLEANERS. Cleaners of this nature will destroy the gasket material.

After processing some foods at low temperatures, odors may linger in the oven. These odors may be cleared by setting the thermostat at 500°F and allowing the oven to operate unloaded for 30 to 45 minutes.

MAINTENANCE

WARNING: THE RANGE AND ITS PARTS ARE HOT. BE VERY CAREFUL WHEN OPERATING, CLEANING OR SERVICING THE RANGE.

SERVICE AND PARTS INFORMATION

To obtain service and parts information concerning this range, contact the Vulcan-Hart Service Depot in your area (refer to the listing supplied with the range), or Vulcan-Hart Company Service Department at the address or phone number shown on the front cover of this manual.